

Buum® roll holder assembly instructions

- Required tools - Allen key SW 5 and possibly a hammer
1. Connect the side parts items 3 and 4 with the lower cross connection item 2
 2. Connect the struts item 5 with the upper cross connection item 1
 3. Connect the upper cross connection item 1 with the two side parts items 3 and 4
 4. Connect the struts item 5 with the lower cross connection item 2
 5. Insert the tube item 6 into the cardboard core of a wiper roll and
 6. Place these in the receptacles on the side parts Item 3 and Item 4

